

# 양방향 오디오 설정 방법

(주) 아이비전


## 카메라 오디오 설정 (Default Setting)

The screenshot shows the camera configuration interface with the 'Audio' tab selected. The left sidebar lists various settings categories like Common, Network, Video & Audio, PTZ, Image, Intelligent, Events, Storage, Security, and System. Under 'Video & Audio', the 'Audio' option is selected. The main panel has two tabs: 'Audio' and 'Audio File'. The 'Audio' tab is active, displaying the 'Audio Input' and 'Audio Output' sections. The 'Audio Input' section is highlighted with a red box. It includes fields for 'Audio Input' (radio buttons for On or Off, currently On), 'Access Mode' (dropdown menu showing 'Line/Mic'), 'Input Volume' (text input field with value '128'), 'Audio Compression' (dropdown menu showing 'G.711U'), 'Sampling Rate(KHz)' (dropdown menu showing '8'), 'Noise Suppression' (radio buttons for On or Off, currently On), 'Channel 1' (dropdown menu showing 'Mic' with a checked 'Enable' checkbox), and 'Audio Output' (dropdown menu showing 'Speaker'). A 'Save' button is located at the bottom of the main panel.

설정을 확인하세요

카메라 공장 출고 설정은  
옆의 이미지와 동일하게 설  
정되어 있습니다.


# GuardStation 접속 양방향 오디오



양방향 오디오 Off

(마우스 커서를 아이콘에 위치하면 “양방향 오디오 시작” 이란 Tooltip이 나타남)

양방향 오디오 On



스피커 볼륨 조정  
마이크 볼륨 조정

# GuardStation 접속 양방향 오디오 동작 확인

